

Use this checklist before every inflatable setup to ensure the safety of all participants.

01

## WIND / WEATHER CHECK

Wind & Weather Monitoring

- Check weather forecasts before every setup (wind, rain, storms)
- Monitor wind speeds continuously during operation
- Do NOT operate in winds exceeding 15-20 mph (check manufacturer specs)
- Have a portable anemometer (wind gauge) on-site
- Establish a clear deflation/shutdown plan for sudden weather changes
- Post "Inclement Weather Action Steps" visibly on the inflatable
- Know the 4 steps: 1) Exit riders 2) Turn off blower 3) Disconnect power 4) Secure

02

## PROPER ANCHORING

Proper Anchoring & Staking

- Inspect all stake points and D-rings before setup
- Use minimum steel stakes driven at 45-degree angle into ground
- Verify all anchor straps are securely attached to stake points
- On hard surfaces: use certified sandbag weights
- Confirm inflatable is level and stable before allowing riders
- Re-check all anchors periodically throughout the event
- Keep backup stakes and anchoring equipment on-site

03

## ADULT SUPERVISION

Always Have Adult Supervision

- Station an adult supervisor who understands the safety rules at every inflatable unit
- Enforce age, height, and capacity limits posted by manufacturer
- No roughhousing, flips, or climbing on exterior walls
- Remove shoes, glasses, jewelry, and sharp objects before entry
- Never leave children unsupervised on or near inflatables
- Keep entrance/exit areas clear and supervised at all times